

# Light barrier amplifier

IMX-A2024...



### Features

- Multichannel amplifier with modulated infrared light
- 2-channel installation system for tight assembly without cross talk
  Range up to 40 m (131 ft)
- Automatic Level Control (ALC) according to assembly distance and direction
- High immunity to ambient light and interference from other light barriers
- Test function to check installation and signal strength
- Adjustment assistance for easy adjustment of the sensor heads
- Switching mode light/dark switchable
- Four basic transmit levels
- One relay output (Form A) for each channel
- Transmitter and receiver connections are short-circuit proof
   11-pin DIN railmounting socket for simple installation

#### Ordering Table

Supply voltage	Order code
230 V AC	IMX-A2024/230VAC
115 V AC	IMX-A2024/115VAC
24 V AC	IMX-A2024/24VAC
24 V DC	IMX-A2024/24VDC
Accessories	Order code
11-pin DIN mounting socket	ISO1
Protective enclosure	PanBox 1x2
Retaining clip	RTC11

### Safety Instructions



**JS160801EN - 08/2016** 

The infrared light barriers IMX-A2024... are not safety systems and should not be used as such systems. The devices are not to be used for applications, where personal safety is dependent on their function.

# Short Description

The 2-channel automatic multiplexer is an processor controlled amplifier with an integrated analysis unit. Up to two transmitters and receivers can be connected to each unit without possibility of cross talk. The automatic gain setting and the adjustment assistance enables the user to simplify the installation and work.

The amplifier has for each channel one relay output (Form A) and a yellow status LED.

All channels can be switched independently from each other to the different working conditions. To make fine adjustments to the sensitivity of the amplifier based on the range and contamination level of the application, the user may switch to different transmit levels using DIP switches.

A control unit, which can be activated by simply pressing a button, is used to determine malfunctions in the transmitter or the receiver.


If nothing is defective, the test function shows the signal quality by flashing an LED from 1 to 10 times. The flashes are proportional to the received signal.

Infrared transmitters and receivers in different, compact and robust designs are described in the sensor heads datasheet.



## Device Overview





#### DIP-switch setting

DIP-switch		1	2	3			4	5	6	
ON 1 2 3 4 5 6	basic tr ch	ansmit annel		switch mod chann	de	basic tr ch	ansmit annel 2		switcl mod chann	de
	high2	ON	ON	با م ما ر	011	high2	ON	ON	والم ما ا	ON
	high1	ON	OFF	dark	ON	high1	ON	OFF	dark	UN
	low2	OFF	ON	li - h t	055	low2	OFF	ON	l'artest.	055
	low1	OFF	OFF	light	OFF	low1	OFF	OFF	light	OFF

Factory setting is marked in dark grey

Switching logic

Beam status	Switching	Output status		
Dealin Status	mode	Indicator	Relay output	
	light	≥⊗≲		
	dark	$\otimes$	- <b>&lt;</b> -	
	light	$\otimes$	- <b>.</b> .	
	dark	≥⊗∈	<b></b>	

Pantron Instruments GmbH · www.pantron.de · sales@pantron.de



# Light barrier amplifier

# IMX-A2024...



# Technical Data (at 20 °C / 68 °F)


Supply voltageAC	230/115/24 V A	C / ±10%	Relay output
Supply voltageDC	24 V DC / ± 10%	)	Switching data (max.)
Power consumption (max.)	AC: 5,1 VA	DC: 2,6 W	Reaction time T <sub>on</sub> / T <sub>off</sub>
Power loss (max.)	AC: n. a.	DC: 2,6 W	
(EN 61439)			Transistor output
max. Range (through beam)	Receiver	Receiver	Alarm output
	IRL	IR, IRH	
Transmitter IT, ITL	7 m ( ft)	13 m ( ft)	Test input
Transmitter ITHP, ITH	9 m ( ft)	20 m (66 ft)	
Transmitter ITA	15 m ( ft)	40 m (131 ft)	MTBF (EN/IEC 61709)
			Operating temperature
Operating basis	modulated IR-lig	ht	Storage temperature
Transmit frequency	4,0 kHz		Housing material
System power	automatic		Housing protection
Switching behavior	light / dark		Mounting
Basic transmit level	Low 1 / Low 2 / H	High 1 / High 2	Mounting orientation
Switching delay	_		Dimensions
Multiplex speed	4 ms		

#### Connection Diagram




Before connecting the amplifier, look on the type plate and check if the power supply is the same as the connection value. Other values can impair the unit functions or destroy the amplifier.

Caution! The AC-supply devices are isolated from main. A grounded connection on the low voltage side is required (PIN 7).



#### Dimensions (in mm)



Pantron 08/2016. Subject to availability. Rights of modification reserved.

**2**/2